

## **POWER CYCLE WEATHER DIRECT GATEWAY**

Weather Direct devices will generally recover from most anomalies on their own within 24 hours. If your Weather Direct device does not recover on its own, you may need to power cycle the gateway.

To power cycle the Gateway:

1. Unplug your Gateway for 10 seconds and then plug it back in.
2. When the Gateway is showing a solid red light...Press and hold the PLUS button on the Display until it beeps (for all audio Weather Direct forecaster units, press and hold SNOOZE until it beeps).
3. Wait 1 minute for the forecast to update (wait 15 minutes for Audio units to update).